

# **REGULATOR RG180LN(SCJ)3/4XLN11/4** PO.340MBAR 25M3/H UPSO R.M., **RV (WITH CONDUCTION) CODE 500103**

With an inlet pressure between 1 and 6bar, the regulator maintains the outlet pressure between 325 and 355mbar for flow rates between 2.5 and 25m3/h.




#### **FEATURES**

- Inlet pressure: 1-6bar
- Output pressure: 325-355mbar
- Securities: UPSO (240mbar) manual reset, RV(550-850mbar)
- Nominal flow rate: 25m3/h
- Pressure tapping: -
- Connections: LN3/4(spheroconical seal)xLN11/4
- Disposition: 180°
- Conduction for venting: F3/4(Whitworth)



#### **DIMENSIONS**









#### **MATERIALS**

- Membranes and seals, in NBR resistant to Liquefied Petroleum Gas (LPG), Natural Gas (NG) and Synthetic Natural Gas (SNG)
- Aluminum body
- Galvanized steel cover
- Cataphoresis treatment with high resistance on cover and body

- Galvanized steel springs
- Non-metallic internal parts, in PA with fiberglass and acetal resin (POM)
- Stainless steel filter
- Manufactured in the EU

#### **COMPLIANCE WITH STANDARDS**

According to EN 88-2:2007 and UNE13611:2019 and EN13611:2019/AC:2021

#### INSTALLATION AND COMMISSIONING


- Check the inlet pressure. It must not exceed 6 bar.
- Fit the regulator respecting the gas flow. See flow arrow on the bottom of the regulator.
- If the regulator has a relief line and is installed indoors, the relief must be piped to the outside through the corresponding pipe connection.
- Once the regulator has been installed, check that there are no leaks at the regulator connections.

- With all consumption points downstream of the regulator closed, open the gas tap upstream of the regulator.
- If the regulator is equipped with automatic VIS MIN, wait a few seconds (approx. 15-20) until the VIS is reset.
- In the case of manual VIS MIN, act on the reset device on the regulator (by pulling on it) for about 2 seconds.
- The controller will start to regulate when any consumption demand occurs.




### **BEHAVIOURAL CURVES**





#### Pe: 2,5bar





## **BEHAVIOURAL CURVES**

